

Bulkhead and Brick Lights Installation Instructions

Location and Maintenance:

When installing in outdoor locations, preference should be given to positions that may be shielded from direct rain and sun (e.g.) higher up on a wall below eaves.

Metal is prone to corrosion over time. You can expect this to occur on metal outdoor lighting, which is exposed to weather. Unlike Superlux Polycarbonate product, these are not guaranteed against corrosion. However, there are measures you can take to prevent corrosion.

- Using a damp cloth, wipe the product clean on a regular basis especially in areas with salt atmosphere.
- Use a car wax on the metal at least once a year to provide a protective coating to the paint.

Installation:

If installing vertically, position the lampholder at the bottom or side.

Wire Connections:

ISOLATE THE ELECTRICAL SUPPLY

- Phase to lampholder centre contact
- Neutral to contact for outer shell
- Earth wire to \perp screw on base
- Use heat sleeves on wires

Lamp E27 - Do not exceed maximum wattage

IP54 - Caulk to building face to maintain IP54 rating.



Gartner Superlux Ltd
AUCKLAND NEW ZEALAND.