

Instructions and assembly Information

## With care and attention to the following information your LSG lamp will give you years of satisfactory service.

- Unpack Lamp Arm assembly and Clamp Base and power cord.
- Choose a suitable position for the Lamp, clamp onto horizontal face only.
- Note: The Lamp is not waterproof Do not use outdoors or in wet areas
- Place the Lamp Arm with 12.7mm diameter Pin into the lamp base.
  Retain the Lamp in Base by tightening the side screw. To secure well use a screwdriver.
- Please use only with the Plug-In Power supply supplied. Connect the cord by pushing the co-axial Cord Connectors together before plugging into your wall socket.
- To switch ON, Touch on O Top of Lamp Head.
- The lamp has 3 selectable light levels 100% > 40% > 10%
- Each Touch steps the Light level down.
- Touch again to turn OFF.

## Important:

۲

- The 2 Wing Knobs must be adjusted as desired, so the Lamp stays in position when moving to different positions.
- Do not move the lamp arm to the extreme limit's forwards and backwards which may cause irreparable damage.
- Do not hang off the arm or the head or hang any items from the lamp.
- Clean the lamp with a dry cloth.
- This product has an Integral LED and has no user serviceable parts. Do not dismantle.
- Do Not cover the Lamp or place against flammable materials.
- If the Power supply adaptor is damaged ensure it is replaced.
- The manufacturer will not be responsible for any damage caused by misuse or modification of this product.

## **Optional Lamp bases are available:**

Drawing Board Bracket	LSM-1
Wall bracket	LSM-3H
Bench Bracket	LSM-4
Heavy Table base	LSM-7
Floor Base	LSM-9



Keep these instructions for future reference

## www.superlux.co.nz

۲

۲